



INSTALL 75-100mm DEPTH APPROVED MULCH. TAPER MULCH DOWN TO MEET PLANT, KEEPING CLEAR OF PLANT STEM.

CULTIVATE ENTIRE GARDEN BED SOIL TO 200mm DEPTH. SPREAD APPROVED IMPORTED TOPSOIL IF SPECIFIED. ADD PRE-MIX SLOW RELEASE FERTILISER IF SPECIFIED.

EXCAVATE PLANTING HOLE THREE TIMES AS WIDE AS THE ROOTBALL AND NO DEEPER THAN THE ROOTBALL. BREAK UP SIDES OF HOLE. LIGHTLY COVER PLANT ROOTBALL WITH SITE TOPSOIL. BACKFILL HOLE AND GENTLY FIRM PLANT AND SOIL INTO PLACE. WATER IMMEDIATELY AFTER INSTALLATION TO ENSURE MOIST ENVIRONMENT FOR PLANT ESTABLISHMENT.



SHRUB PLANTING
DETAIL CROSS SECTION

SCALE 1:10